Parata PASS™ 576VP Variable Pouch Packager

Key Features	**Variable Pouch Sizes:** With multiple selections available, pouch size can change for each batch.
	Intuitive Software: Flexible and easy to use, Parata PASS Ware® software offers a wide range of reporting, and a drag-and-drop editor to customize pouch design,
	Scalability: Smart canisters extend capacity beyond the standard configuration. Store additional canisters outside the unit and swap them in as needed.

|	
Capacity	Up to 576 canisters (or unique NDCs) at one time
Pharmacy Software Integrations	Parata integrates with nearly 50 host systems
Pharmacy Software Integrations	More than 70
Included with Your Purchase of a Parata PASS Packager	- NDC specific canisters (576) and canister labels - Special tablet trays (3) - Laser printer (1) and Dymo printer (1) - Precisa LS 2200C Scale - Cleaning kit - PASS Pack boxes, assorted - Paper (3 rolls) and ribbon (3) - Parata PASS Ware license and workstation, which includes: standard PC tower, - 24-inch widescreen monitor, keyboard, mouse, printer, and barcode scanner
Optional Complements	- Parata PASS Safe Loader® Lighted Tray - Parata Perl® Pouch Inspector - Parata Pivot® Workflow Software - Additional Lower Packaging Unit - iRolly, Winder DE

Network Requirements	Ethernet RJ-45
Power Requirements	PASS Packager: One dedicated 120V / 60Hz outlet within 6 feet of the packager. PASS Ware Workstation: Connection to uninterruptable power supply (UPS) and access to 120 V / 15A / 60Hz outlets.

Parata®

Parata PASS™ 576VP Variable Pouch Packager

Position high-volume medication canisters — available in three sizes at removable panel for easy refilling.

Ensure a match between the drug and smart canister with barcode scanning.

Create variable pouch sizes (55, 65, 75, 85, or 95mm) by batch.

Expect flexibility and control with easy-to-use software.

Manage one-off meds, OTCs, half tabs, and more with STS trays.

Retrieve PASS strips easily after packaging.

Roll out Lower Packaging Unit (LPU) for service or to swap with another unit.

Dimensions	Width (in)	Height (in)	Depth (in)
Packager	50	86	40
Total Space	122	92*	108

You'll also need counter space for the PASS Ware workstation.
*During assembly, 105-inch height space is needed.

Weight	Unloaded (lb)
Packager	1,962

Front side

8"
36"   Parata PASS 576VP   36"
60"

Parata®